

## Motor Installation

Thank you for purchasing a World Chemical's magnetic drive pump. Here are the instructions to install a motor to the pump.

1. The pump is shipped as shown below (except a pump base). Loosen bolts to detach the front casing from the bracket.
2. Insert the outer magnet into the bracket.



Fig. 1




Fig. 2

3. Attach the rear casing support and the front casing to the bracket, and tighten the bolts.
4. Attach a motor to the bracket and tighten the bolts provided.



Fig. 3



Fig. 4

 **WORLD CHEMICAL USA, INC.**  
[www.worldchemicalusa.com](http://www.worldchemicalusa.com)